

TracVision® A5 AC/DC Converter Wiring Instructions

The following instructions explain how to wire the AC/DC converter between the TracVision A5 receiver and the vehicle's AC power supply.




Figure 1
*AC/DC Converter and
Connecting Cables*

1. Plug the AC/DC converter's receiver power cable into the "Vehicle Power" jack on the TracVision A5 receiver's rear panel.




Figure 2
*TracVision A5 Receiver
Power Connection*

2. Plug the AC/DC converter's AC power cord into the vehicle's AC power supply.